

510 Smart PCC Instructions

Charging operation principle: Smart PCC is recharged through the wall adapter, then the PCC is used to charge the 510 batteries.

There are two steps to check the PCC:

Step One: To inspect if there charge level of the PCC battery

Step Two: To inspect if the e-cig battery can be recharged by the PCC

Detailed Instructions:

Step One:

Checking the power level of the Smart PCC from the LCD display

Press the button to light up the LCD screen, read the indicator and refer to the table below

Indicator	Description
Strips displayed on the screen	Power is indicated by the strips in the display The more strips displayed, the more power left Recharge is needed when there is no display
Indicator light blinks red	The Battery in the PCC needs to be re-charged
Indicator Light is green	Battery is charge and ready for use

Step Two:

Charging e-cigs batteries

Place the battery to be charged into the back battery slot of the PCC and close the lid.

Action	Indicator Light	Battery Status
Press and hold the button for 3 to 5 seconds	Blinks green then stays red	Battery is starting to be charged
	Blinks green then stays green	Battery is fully charged
	Blinks green then goes out	Battery is not in the slot or bad connection
Click the button	Indicator is Red	Battery is still charging

Note: If the screen shows full strips but the e-cig still has no power, please make sure that the PCC is fully charged and that the battery connector is not dirty.